



Sony ICFC1T Battery Replacement

Instruction on how to replace the battery for your alarm clock. You will need a CR2032 battery, it should only take about 2-5 minutes to replace.

Written By: Anna Graetz



INTRODUCTION


This guide will give step by step instructions on how to replace your battery.



PARTS:

- [CR2032 Lithium Battery](#) (1)
-

Step 1 — Battery



- Remove the battery compartment from the underside of the device.
- With your thumb and index finger, pinch the tab and pull gently until the compartment is released.

⚠ Always ensure that the device is unplugged before tampering with it to ensure there is no risk of electrical shock.

Step 2



- Take out old battery by pressing from the side marked "**PUSH**" on the compartment, and replace with a new battery, positive side up.

Step 3



- Replace the battery compartment into the bottom of the device.
- Reset the time of the clock.
- ⓘ Plug your clock back in as to not rely on the back up battery.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-09 10:38:15 PM.